

1. Rough opening measurements

Small Cabin Light

14 $\frac{3}{4}$ " Inside Vertical
14 $\frac{3}{4}$ " Inside Horizontal
6 $\frac{7}{64}$ ", 45° Corner Brace

Cabin Light / Rambler

22 $\frac{1}{4}$ " Inside Vertical
22 $\frac{1}{4}$ " Inside Horizontal
9 $\frac{11}{64}$ ", 45° Corner Brace

Large Cabin Light/Large Cabin Breeze

23 $\frac{5}{8}$ " Inside Vertical
23 $\frac{5}{8}$ " Inside Horizontal
9 $\frac{29}{32}$ ", 45° Corner Brace

Rambler Breeze

22 $\frac{3}{4}$ " Inside Vertical
22 $\frac{3}{4}$ " Inside Horizontal
9 $\frac{27}{64}$ ", 45° Corner Brace

**Tall Cabin Light/
Tall Rambler**


36 $\frac{1}{4}$ " Inside Vertical
22 $\frac{1}{4}$ " Inside Horizontal
9 $\frac{11}{64}$ ", 45° Corner Brace

Tall Rambler Breeze


36 $\frac{1}{4}$ " Inside Vertical
22 $\frac{1}{4}$ " Inside Horizontal
9 $\frac{27}{64}$ ", 45° Corner Brace

Town Light Window


See reverse side



2. Build rough opening and install corner braces per recommended inside measurements (see 1).
3. Trace rough opening and cut out sheeting.



4. Wrap with moisture barrier and slice across corners of octagon, extend the cut on the top three flaps.





5. Temporarily fold and tape top three flaps up. Fold rest of the flaps into opening, staple to frame and trim excess.

6. Tape flex wrap to bottom half of rough opening.



7. Apply sill tape.

8. Apply caulk to edge of rough opening except for the bottom panel.


9. Insert window and fold the top three flaps back and trim along the edge of the brickmould line.




10. Level and center window.



11. Fasten window through nail fin/brick mould to wood framing using nails or pan head screws.



12. Tape over moisture barrier cut lines and exposed nails with flashing tape. * for brickmould, tape along with a 3/4" overlap on brickmould.




13. Apply drip cap to top of window.

14. Apply window and door foam insulation form inside of wall.

▲ Use only foam product for window and door, other types may distort the window and void warranty.

a. siding
b. moisture barrier
c. sheeting
d. stud and foam
e. drywall




JJJ SPECIALTY CO.

Octagon Window

Town Light Instructions on back.

JJJ Specialty Co.
ph: 612-788-9688
fax: 612-788-2002
info@jjjspecialty.com

Town Light Installation Instructions




1. Rough opening measurements

Town Light Stationary
 22-1/4" Inside Vertical
 22-1/4" Inside Horizontal
 9-11/64", 45° Corner Brace


Large Town Light Stationary

23-3/4" Inside Vertical
 23-3/4" Inside Horizontal
 9-11/64", 45° Corner Brace

- Build rough opening and install corner braces per recommended inside measurements (see 1).
- Trace rough opening and cut out sheeting.



- Wrap with moisture barrier and slice across corners of octagon, extend the cut on the top three flaps.




- Temporarily fold and tape top three flaps up. Fold rest of the flaps into opening, staple to frame and trim excess.

- Tape flex wrap to bottom half of rough opening.

- Apply sill tape.


- Apply caulk to edge of rough opening except for the bottom panel.

- Insert window into opening and tack through top vinyl strap and fold the top three flaps back and trim along the edge of the brick mould line.




- Level and center window into opening. Then from inside use side straps to pull window in tight and tack through straps to hold in place.

- Secure into opening with screws or nails through side jambs. Cut straps and discard after unit is installed.





- Tape over moisture barrier cut lines and exposed nails with flashing tape. * for brickmould, tape along with a 3/4" overlap on brickmould.



- Apply drip cap to top of window.

- Apply window and door foam insulation from inside of wall.

▲ Use only foam product for window and door. Other types may distort the window and void warranty.



- a. sliding
 b. moisture barrier
 c. sheeting
 d. stud and foam
 e. drywall

Please read these instructions in their entirety before beginning to install this window product.

These installation instructions demonstrate the installation of a wood or vinyl window in new wood frame construction using an industry approved water management system. For installation using other construction methods, such as remodeling, replacement, and recessed openings refer to "ASTM E2112-01, Standard Practice for Installation of Exterior Windows, Doors and Skylights," for installation suggestions. Information for ASTM E2112 can be found on the ASTM website, www.astm.org.

Regional standard practices, environmental conditions, and codes may vary and supersede the procedures contained within. The responsibility for compliance is yours: the installer, inspector, and owner(s).

The procedures within these instructions are consistent with those used in testing.

You Will Need to Supply

- Safety glasses
- Hearing protection
- Level - Square
- Hammer
- Wood shims
- Casing Nails
- Insulation
- Tape measure
- Perimeter sealant
- Sill pan flashing
- Backing material (foam backing rod)
- Low expansion foam insulation
- Flashing materials
- Weather resistive barrier

WARNING

Drilling, sawing, sanding or machining wood products generates wood dust and other substances known to the State of California to cause cancer.

Avoid inhaling dust generated from wood products or use a dust mask or other safeguards to avoid inhaling dust generated from wood products.

Wood products emit chemicals known to the State of California to cause birth defects or other reproductive harm.

California Health and Safety Code Section 25249.6